

Mitel VoIP 420G Non-Color Phone



Welcome to your new phone! Below are a few quick tips of basic functions you'll want to know about. The pages following highlight other features and functions of the phone that could come in handy.

Voicemail setup:

The initial password for your voicemail is 1234. If you forget your password or are unable to login, please submit a Helpdesk Ticket through SchoolDude.

Change your password

Login to your voice mail. When you hear the prompts, selection option 7 for mailbox options. Select option 4 to set password. Follow the prompts. Hang up when finished.

Change your recorded name

Login to your voice mail. When you hear the prompts, select option 7 for mailbox options. Select option 6 to record your name. Follow the prompts. Hang up when finished.

Record a new personal greeting

Login to your voice mail. When you hear the prompts, select option 7 for mailbox options. Select option 1 to record a personal greeting. Follow the prompts. Hang up when finished.

Below are the several different ways that you can check your voicemail:

From your classroom/office phone:

If you're on one of the non-color phones, press the voicemail button and the follow the prompts



From any phone in the district:

If you're on one of the non-color phones, press the voicemail button and then follow the prompts

From outside the district:

Call 586-439-4400 and when you hear the greeting, press the * button and follow the prompt. You will be asked to enter your extension and then your password followed by the #



Mitel Phone Basics

Placing Calls

To Place an Internal Call Using the Keypad – Pick-up the handset or Press the speakerphone button and then dial the extension number.

To Place an External Call Using the Keypad – Pick-up the handset or Press the speakerphone button and then press 8 and dial the phone number, include a 1 if it is a long-distance call.

To Place an External Call Using the Directory – Pick-up the handset or Press the speakerphone button and then press the directory button. Use the up/down navigation keys to scroll or enter the first three or four characters of the last name of the person you are calling. This will bring you to the portion of the directory in which you can use the navigation keys to highlight the person you want to dial and then press the dial soft kev.

To Place a Conference Call Using the Keypad – Pick-up the handset or Press the speakerphone button and then press Conference button and dial the phone number, include a 8 for an outside line and a 1 if it is a longdistance call then press the Confer or Consult soft key.

Answering Calls

To Answer a Call – Pick-up the handset or Press the speakerphone button. To Send a Call to voicemail – Press the Voicemail button or the To VM softkey.

Placing a Call on Hold or Picking up a Call on Hold

To Place a Call on Hold – Press the Hold button or press the call appearance button.

To Pick-up a Call on Hold – Press the Hold button or press the orange blinking call appearance button.

Transferring a Call

To Transfer a Call – Press the transfer button, dial the extension number and then press the Transfer softkey or the Consult soft key.

Mute or Un-Mute a Call

To Mute a Call - Press the button.



To Un-Mute a Call - Press the hutton



Call or Ringer Volume

To Adjust the Volume of a Current Call - Press the - or + button to adjust the volume of the handset or speaker during an active call.

To Adjust the Volume of the Ring Tone – Press the – or + button to adjust the volume of the ring tone.

Voicemail

To Check Voicemail – Press the voicemail button, enter your password using the keypad and press OK.

Log in To Voicemail - Press the Voicemail button, Press the Call VM softkey enter your password using the keypad and press the # key.

To Check your Voicemail from another extension – Press the Voicemail button, Press the Call VM softkey, press the # key, enter your Extension number, enter your Password and press the # key.

IP PHONE 420/420G QUICK REFERENCE



PHONE OPERATION

Place calls

Use the handset, the speakerphone, or a headset

Lift handset or press



Make a blind conference call

+ ext. +

Make a consultative conference call

to select + ext. + wait +

Use the Directory

to select +

Dial from History

Note: To close Directory or History, press that key again.

Answer calls

Answer a call

Lift handset or press (◀»)

Answer call waiting (incoming call)

Press blinking call appearance button

Answer an off-screen incoming call

while offscreen call is displayed

Interact with calls

Adjust volume of handset, headset, or speakerphone when off hook; adjust ringer volume when on hook

Mute a call

Place a call on or off hold

Transfer a call (blind)

Transfer a call (with a consultation)

Divert an incoming call to Voicemail

(- +) to select





Press and hold









Adjust the display contrast

VOICEMAIL

Log in to Voicemail Main Menu

Log in from another extension

Voicemail + Password + #

+ # + Ext. + Password + #

Log in or out of workgroup

+ Password + # + 7 Pass Wyyz BEF

Change availability state

+ Password + # + 7 ABC ABC Voicemail

Change extension assignment

+ Password + # + 7 3 DEF ABC Voicemail

+ Password + $\begin{bmatrix} # \\ \end{bmatrix}$ + $\begin{bmatrix} 7 \\ PORS \end{bmatrix}$ $\begin{bmatrix} 3 \\ DEF \end{bmatrix}$ $\begin{bmatrix} 1 \\ \end{bmatrix}$

Unassign extension assignment

+ Password + $\begin{bmatrix} # \\ \end{bmatrix}$ + $\begin{bmatrix} 7 \\ PQRS \end{bmatrix}$ $\begin{bmatrix} 3 \\ DEF \end{bmatrix}$

EXTENSION ASSIGNMENT CODES

Assign extension to external number

Transfer a call * + destination + # #

Conference a call * + destination + *

Hold a call * * Hang up # | #

Access other star codes * + (numerical code from list below)

Voicemail

QUICK REFERENCE OF COMMON STAR CODES

Park a call

Unpark a call

 $\begin{bmatrix} \mathbf{1} \end{bmatrix} \begin{bmatrix} \mathbf{3} \\ \mathsf{DEF} \end{bmatrix} + \mathsf{ext}.$ Pick up a Remote Extension

* 1 4 Pick up the Night Bell

* 1 5 Use the Intercom

1 6 MNO Barge In 1 7 + ext

+ Hunt Group's ext. Toggle the Hunt Group status

* 1 9 + ext. Whisper Page * 2 ABC + CXT Silent Coach

TROUBLESHOOTING

Silent Monitor


4 6 3 6 # (INFO#) View phone information


7 3 DEF 7 B B TUV # (RESET#) Reboot your phone

Note: For details about using the phone, see the IP Phone 420/420g User Guide.

IP PHONE 420/420G QUICK REFERENCE







STATUS ICONS

These icons are displayed on the phone to indicate operational status:

- Off-screen call (on main display)
- Voicemail message indicator (on main display)
- Secure call
- Missed call (on main display and in History)
- Inbound call (in History)
- Outbound call (in History)
- Transferred call (in History)
- Workgroup Agent logged in
- Workgroup Agent logged out
- Workgroup Agent wrap up

- Minking Green (Fast): Call on hold or call parked
- Blinking Green (Slow): Incoming call

MITEL VOICEMAIL QUICK REFERENCE



Voicemail Operations

New Voice Mail Indicators

Your voice mailbox contains unplayed messages if:

- You hear a stutter tone on the handset.
 OR
- · The phone's message waiting light flashes.

Checking Voice Mail

To check voice mail from your extension

- 1 Press or lift the handset and press #.
- 2 At the prompt, use the dial pad to enter your password. (If you have not been assigned a password, use the default password, 1234.)
- 3 Press #

NOTE: If you are logging in for the first time, the system prompts you for a new password and asks you to record your name.

To check voice mail from another extension

- 1 Press # twice.
- 2 Enter your extension.
- 3 Enter your password.
- 4 Press #

To check voice mail from an external phone

- 1 Dial your voice mail access number.
- 2 Enter your extension.
- 3 Enter your password.
- 4 Press #.

Listening To Messages

At the Main Menu prompt, press **1**. The voice mail system plays urgent messages first, then newly arrived messages.

The system gives the delivery date and time for each message. (You can disable this feature from the Mailbox Options Menu.)

Managing Messages

After listening to a message, you can replay it, send a reply to the person who left the message, forward it to someone else, replay the date and time information, save it, or delete it.

To replay all of your saved messages

• Press 3 at the Main Menu prompt.

As a safeguard against accidental erasures, the system retains deleted messages for a few hours.

To listen to your deleted messages

- 1 Press 7 at the Main Menu prompt.
- 2 Press 7.

Voice mail plays all the deleted messages still available to the system. During playback, you can manage deleted messages as if they were newly arrived messages.

To restore a deleted message

Press 2.

To send a recorded message from voice mail

After recording a message, voice mail asks you to supply an address.

- 1 Address the message to individual recipients by entering their extension numbers.
- 2 Specify groups of recipients by entering a distribution list number.

To identify a recipient by name, specify a personal distribution list, or broadcast to all extensions, press **0** and follow the prompts.

To mark a message as urgent

• After addressing the message and confirming the addressee(s), press 1.

To forward the message you're reviewing

1 Press 4 and follow the recorded prompts.

To reply to the message you're reviewing

- 1 Press 5 and follow the recorded prompts.
- 2 Press 1 to reply with a voice mail, press 2 to reply with a call back, or press 3 to reply to all with a voice message.

Changing Mailbox Options

Personalize your voice mail by changing your name, password, or personal greeting.

To change personal settings from the Main Menu, press **7** and follow the recorded prompts.

Enabling Office Anywhere (On-Net)

If you have the proper permission, you can assign your extension to any phone on the system.

- 1 Log in to voice mail from the target phone an extension other than your own.
- 2 At the Main Menu prompt, press 7.
- 3 Press 3 to re-assign the extension.
- Press 1 to assign the extension.
- Press 2 to un-assign the extension.
 (Phone reverts to its original extension.)

(Off-Net Extension Re-assignment cannot be configured through the voicemail system and must be configured through PCM. Refer to the Administration Guide for details.)

Setting Availability and Forwarding

NOTE: Use ShoreWare Call Manager to configure the states with different call forwarding destinations and personal greetings.

You can set one of the states for your extension. When you record a personal greeting, it is linked to the active Availability state.

To enable one of the distinct states:

- Press 7 at the Main Menu prompt.
- Press 2, then follow the prompts.

Changing Notification Options

To select a notification profile for the Escalation Notification feature:

- Press 7 at the Main Menu prompt.
- Press 9 for additional mailbox options.
- Press 2, then follow the prompts.

NOTE: You must have notification profiles previously configured before a notification profile can be activated

Enabling FindMe

To enable or disable FindMe Forwarding so that callers can forward their calls to your destination:

- Press 7 at the Main Menu prompt.
- Press 9 for additional mailbox options.
- Press 5, then follow the prompts.

NOTE: You must have permission to use FindMe Forwarding.

Leaving a Message

Troubleshooting

If the number of messages in your mailbox exceeds the limit, the system notifies callers that your mailbox is full and unable to accept new messages. (Recently deleted messages remain in the mailbox and are included in the total count.)

If your mailbox is full, first purge any backlog of deleted messages.

To purge deleted messages

- 1 At the Main Menu prompt, press 7.
- 2 Press 8 to remove deleted messages.
- 3 Press 1 to confirm deletion or * to cancel.

Leave Message

When dialing into a ShoreTel system, if the person you are trying to reach does not answer, your call will be sent to a mailbox and you will hear a standard greeting. You can select from the following options:

- # Bypass greeting
- Transfer to assistant
- 1 Forward to recipient's FindMe destination
- 9 Transfer to Auto-Attendant

Message Recording

If you choose to leave a recorded message, the following options are available after recording your message:

- # Message options
- * Re-record
- Send message, transfer to assistant
- **1** Send message, forward to recipient's FindMe destination
- **9** Send message, transfer to Auto-Attendant

NOTE: Hanging up sends the message.

Message Options

When leaving a message, select from the following options:

- # Send message
- * Cancel
- 1 Review
- 2 Re-record
- 3 Mark/unmark urgent
- Send message, transfer to assistant
- 9 Send message, transfer to Auto-Attendant

MITEL VOICEMAIL QUICK REFERENCE



Main Menu for Voice Mail Operations



Select one of the following options during or at the end of a message:

O Additional options 1 Replay

2 Save

3 Delete

Listen to Messages

- 4 Forward 5 Reply
- 6 Play envelope 7 Move backward

5 Reply

Select one of the following:

- 1 Reply with a voice mail
- 2 Reply with a call back 3 Reply to all with a voice
- message

Log In: Internal

- a) From your own extension, lift the handset, press #, enter password, and press #
- b) From another extension, press # twice, enter extension, enter password, and press #

Call your voice mail access number, enter extension,

Log In: External

enter password, and press #

Send a Message

Record your message at the tone. When finished, press # and select from the following options:

- # Accept
- 1 Review
- 2 Re-record
- * Cancel

Conclude Addressing

- # Send
- 1 Mark/unmark urgent
- 2 Mark/unmark for return receipt
- 3 Enter additional addresses
- * Cancel

0 Addressing Options

1 Address by name

3 Re-assign Extension

1 Assign to this telephone

3 Assign ext. to last external

- 2 Address by personal distribution list
- 3 Broadcast

1 Address by Name

Spell the name of the person, last name first. Press 7 for Q and 9 for Z. * Cancel

Note: System returns to Addressing after name is entered.

2 Address by Personal Distribution List

Enter the two-digit personal distribution list number. * Cancel

Listen to Saved Messages

Refer to "Listen to Messages" for message options while listening to saved messages.

- 2 Set Availability state
- 4 Set password
- 5 Enable/disable envelope information
- 8 Remove deleted messages
- 9 Additional options
- * Cancel

1 Record Greeting

8 Pause

Skip

Accept

** Cancel

* Cancel

Conclude addressing -

* Cancel last address

9 Move forward

Enter the extension or the system

0 Additional addressing options —

distribution list to receive the message:

Record your greeting for the currently active mode at the tone. When finished. press # and select from the following options:

- # Accept 1 Review
- 3 Delete * Cancel

5 Custom

* Cancel

6 Do Not Disturb

- 2 Re-record

1 Available

4 Vacation

2 In a meeting

3 Out of office

2 Set Availability State

4 Set Password

2 Un-assign

number

* Cancel

Enter password twice in response to the prompts.

* Cancel

5 Enable Envelope Info

Press either 1 to enable. or 2 to disable

6 Record Name

Record your name at the tone. When finished, press # and select from the following options:

- # Accept 3 Delete
- 1 Review * Cancel
- 2 Re-record

8 Remove Deleted Messages

1 Confirm * Cancel

9 Additional Options

- 1 Enable or disable Outlook automated call handling
- 2 Change notification options
- 3 Change agent state
- 5 Change Find Me Forwarding state
- * Cancel

2 Notification Options

- 1-9 Enter the number associated with a Notification Profile
- Disable Notification
- # No change

3 Agent State

- 1 Log in and assign extension
- 3 Log in without assigning extension

5 Find Me Forwarding

- 1 Enable Find Me Forwarding
- 2 Disable Find Me Forwarding

Change Mailbox Options

- 1 Record greeting -
- 3 Re-assign extension

- 6 Record name
- 7 Listen to deleted messages

Loa Off



Return to Auto-Attendant



Transfer to Assistant

Hear Mailbox Status